


Roomcast™

Custom User Interface Service

Create an interface to compliment your hotel brand. Using your images, logos and colours TeleAdapt can work with you to create a custom UI. Please contact us for pricing for this additional service.

Welcome page custom options :



Subsequent pages

For all other pages, you have the option to add an extra background. If you do this, your first background image will only show on the welcome page, with the extra image showing on all subsequent pages.

Image and logo Specification

All background images should be 16:9 aspect ratio

Minimum resolution 1280px * 720), .jpeg or .png

All logo images can be any size (maximum 1500px * 800px), but they must be .png

Adding the custom UI to Roomcast - Reference the Installation guide / setup Wizard

The property copies the UI and configuration file from their rc.teleadapt.com account to one or more USB drives.

For each room:

1. Insert a prepared USB drive into Roomcast rear USB and power on
2. Roomcast will update the UI.
3. Roomcast will enter Setup Wizard, the hotel enters the System ID and PIN code and applies the configuration file.
4. The room number will need to be entered for each unit
5. Roomcast will configure itself, we would recommend unit is re-powered at this stage.
6. Roomcast is ready for use.