

Roomcast™

Guestroom Instructions

Your favorite TV shows, movies, videos, music, and photos are on your phone, tablet, and laptop. Stream from your apps to the TV in your room.

Roomcast is powered by Chromecast and supports 1,000s of apps. It's easy. You don't need to download new apps or share your user names or passwords.



1 With the TV on, press SELECT on the remote control to open the WELCOME screen



Chromecast

Cast from your device to the TV



Bluetooth

Stream your audio to the TV speakers



Hotel TV

Return to regular TV viewing



Information

Learn more and leave feedback

2 Connecting to Chromecast

Select the Chromecast icon to join the dedicated network. Typically the network name is your room number. The system creates a unique password that only you can see.

After you connect your mobile device you will have access to Chromecast.

When you're ready to cast, select "Switch to Chromecast" or "Start streaming" on your device and you will see a screen saver image.



The Cast icon

This will only show up in your apps after you've connected to the Roomcast WiFi (follow the onscreen instructions for network name and password)

3 Using Chromecast

To cast, you simply open a cast-enabled app and tap the Cast icon. It's that simple. Thousands of apps have the cast functionality built in.

Once you have started a cast session, you can exit the app and check email, surf the web, etc. and your cast will continue playing.

Additional guests in the room can join the network and cast from their devices.

A new cast simply takes over from an existing cast.

To stop casting, press the Cast icon within your app again and select "Disconnect".

Roomcast™

Guestroom Instructions

Questions and trouble shooting....

I press the remote's "Select" button but nothing happens

The remote control could need batteries or needs pairing to the Roomcast box. It could also be some settings on the TV have been altered. Please call the front desk.

I see a blue screen that says "Set me up" or "Reconnect me"

This means Chromecast is not connecting to the internet properly. Call the front desk so they can check that the Roomcast box is connected to the internet.

I see the Roomcast WELCOME screen but I cannot move around... the remote seems frozen

Press the "Select" key again, and check if this enables the cursor to move around as expected.

I don't see the Cast icon on my phone or tablet

It will only show up if your mobile device is connected to the Roomcast (follow the onscreen instructions to connect to your room's personal area network.

Look for it in a music or video app like Netflix, Spotify, or any other cast-enabled app. There are over a thousand of them.

How to cast from a laptop

Casting is possible from laptops by using the Chrome browser. Whatever you have in the browser can be cast to the TV (even videos). To find the Cast button, expand the menu on the far right of the browser signified by 3 vertical dots. Note that casting from the browser is not as fast and high-def as casting from a mobile app.

How to cast from a different device

While one person is casting, another person can take over and cast from their device. Just press the "Cast" button and it will over-take the session on the TV screen.

Make sure any additional device you wish to cast from first connects to the Roomcast WiFi.

How to stop a cast session

Press the "Cast" button again and select "Disconnect".

How to exit Chromecast and watch regular TV

If you're casting, press the "Select" button and it will switch you from Chromecast to the Roomcast WELCOME screen. Here you can select "Exit to TV".

I connected to Roomcast earlier, but my phone is no longer connected

The Roomcast password changes daily and you will need to use the current password to reconnect.

Sometimes phones auto-connect to a previous WiFi connection. Double check your WiFi settings and make sure your device still shows it's connected to your room's personal area network. The Roomcast WiFi network name is typically your room number (e.g. Room501).